








	CYLINDER HEAD COVER B-2-1		CYLINDER HEAD B-3		CYLINDER B-4		CRANKCASE B-5		CRANKCASE RH COVER B-6		CRANKCASE LH COVER B-7
	CRANKSHAFT B-8		CRANKSHAFT BALANCER B-10		STARTER CLUTCH B-11		CAM SHAFT - VALVE B-12		CAM CHAIN B-14		

AIR CLEANER...C-4 CLUTCH.....C-7 CYLINDER HEAD COVER...B-2 FUEL TANK.....E-6 MUFFLER.....C-5 RH HANDLE SW....F-3 TURN SIG.LAMP..D-11 FOR SPECIAL MARKET
 BATTERY.....D-6 CONTACT BREAKER...D-5 ELECTRICAL.....D-13 GEAR SHIFT...C-10 OIL PUMP.....C-6 SEAT.....E-9 WIRING HARNESS..D-14 E2 spec.....H-2 E25 spec.....K-7
 BRAKE HOSE...F-7 CRANKCASE.....B-5 FRAME.....D-15 GENERATOR.....D-4 OPTIONAL.....G-2 SPEED/TACHO...D-7 E4 spec.....H-9 E30 spec.....L-2